



MANUAL

EM1060 - 12-in-1 Cardreader USB 2.0

WWW.EMINENT-ONLINE.COM

EM1060 - 12-in-1 Cardreader USB 2.0



Warnings and points of attention

Opening a product and/or products may cause serious injuries! Always have products repaired by qualified Eminent personnel!

Table of contents

1.0 Warranty conditions.....	2
2.0 Introduction	2
2.1 Functions and features	3
2.2 Packing contents	3
3.0 Installation procedure	3
3.1 Driver installation (Windows 98SE)	3
3.2 Installing the software	4
3.3 Installing the USB Cardreader	4
4.0 Reading out a SIM card	4
4.1 Functions of SIM card editor 3.0	5
4.2 Managing telephone numbers	5
4.3 Managing SMS messages	5
4.4 Making a backup	5
5.0 Frequently Asked Questions.....	6
6.0 Service and support.....	6

1.0 Warranty conditions

The five-year Eminent warranty applies for all Eminent products unless mentioned otherwise before or during the moment of purchase. When having bought a second-hand Eminent product the remaining period of warranty is measured from the moment of purchase by the product's first owner. The Eminent warranty applies to all Eminent products and parts indissolubly connected to and/or mounted on the main product. Power supply adapters, batteries, antennas and all other products not integrated in or directly connected to the main product and/or products of which, without reasonable doubt, can be assumed that wear and tear show a different pattern than the main product are not covered by the Eminent warranty. Products are not covered by the Eminent warranty when exposed to incorrect/improper use, external influences and/or when opened by parties other than Eminent.

2.0 Introduction

Congratulations on your purchase of this high-quality Eminent product! This product has undergone extensive testing by Eminent's technical experts. Should you

experience any problems with this product, you are covered by a five-year Eminent warranty. Please keep this manual and the receipt in a safe place.

Register this product now on www.eminent-online.com and receive product updates!

2.1 Functions and features

With the USB Cardreader you can read and write all popular memory cards! The 12-in-1 Cardreader allows you to connect your SIM telephone card as well. When using the enclosed SIM Card editing software, you can edit your phonebook and SMS messages and save it to your computer.

The USB Cardreader supports the following memory cards: Mini SD, Micro SD (T-Flash), Secure digital, Multimedia card, Multimedia card plus (MMC), RS-MMC (MMC Mobile), MMC card 4.0, RS-MMC4.0 (MMC Mobile 4.0), MMC micro, MS / MD Duo / MS PRO DUO and SIM card.

2.2 Packing contents

The following parts need to be present in the packing:

- EM1060, 12-in-1 Cardreader USB 2.0.
- USB extension cable.
- CD-rom with drivers and manuals.
- Manual.

3.0 Installation procedure

Follow the steps below to install the USB Cardreader on your computer.

In case you have Windows 98SE, then continue with section 3.1.

If you have Windows ME, 2000 or XP you don't have to install drivers on your computer to use the USB Cardreader. These versions of Windows have built-in drivers for this product. Installation will occur automatically. In case you have Windows ME, 2000 or XP, then continue with section 3.2.

3.1 Driver installation (Windows 98SE)

1. Place the enclosed CD-rom in the CD-rom or DVD station of your computer.
2. The CD-rom will start automatically.
3. Select your language.
4. Click 'Next'.
5. Select 'Setup for Windows 98SE'.
6. Click 'Next'.

7. Follow the installation steps as displayed on your screen to finish the installation.

You can also start the wizard manually when the CD-rom does not start automatically. Go to 'Start', 'Run', typ 'x:\wizard\wizard.exe' ('x' is the drive letter of your CD-rom station) and press enter.

3.2 Installing the software

1. Place the enclosed CD-rom in the CD-rom or DVD station of your computer.
2. The CD-rom will start automatically.
3. Select your language.
4. Click 'Next'.
5. Select 'Install SIM software'
6. Click 'Next'.
7. Follow the installation steps as displayed on your screen to finish the installation.

You can also start the wizard manually when the CD-rom does not start automatically. Go to 'Start', 'Run', typ 'x:\wizard\wizard.exe' ('x' is the drive letter of your CD-rom station) and press enter.

3.3 Installing the USB Cardreader

1. Connect the USB Cardreader to an available USB port on your computer. We recommend using a USB2.0 port when your computer has USB2.0 ports.
2. Windows will recognize the USB Cardreader automatically.
3. Put your memory card carefully in the card reader.
4. You will now see an additional 'Removable Disc' in Windows Explorer.
5. You can view, change or remove the contents of the memory card by accessing the removable disc.


Hint! If your USB Cardreader does not fit into the USB port of your computer, you can use the enclosed extension cable.

4.0 Reading out a SIM card

The USB Cardreader can also read out SIM cards, besides reading out memory cards. This allows you to maintain your telephone numbers and SMS Messages.

1. Put the SIM card carefully in the card reader.
2. Click 'Start'.
3. Select 'Program's' or 'All Program's'.
4. Select SIM editor.
5. Click 'SIM card editor 3.0' to start the program.

4.1 Functions of SIM card editor 3.0



- | | |
|----------------------|----------------------|
| (1) Copy to SIM | (8) Add |
| (2) Copy to computer | (9) Refresh Data |
| (3) Save on computer | (10) Phonebook |
| (4) Copy | (11) SMS messages |
| (5) Paste | (12) Backup function |
| (6) Cut | (13) End program |
| (7) Delete | |

4.2 Managing telephone numbers

1. Click in the menu on the left on 'Phonebook' (nr. 10).
2. The phone numbers will be loaded and displayed on your screen.
3. Click 'Add' (nr. 8) when you want to add a new telephone number to your phonebook. Enter the data of your contact.
4. Check a contact and click 'Delete' (nr. 7) when you want to delete a contact from the phonebook.
5. Double click a contact when you want to change the data of an existing contact.

4.3 Managing SMS messages

1. Click in the menu on the left on 'SMS messages' (nr. 11).
2. The SMS messages will be loaded and displayed on your screen.
3. Check a message and click 'Delete' (nr. 7) when you want to delete a SMS message.
4. Check a message and click 'Copy to computer' (nr. 2) when you want to copy a SMS message to your computer.

4.4 Making a backup

The SIM card editor has a very useful backup function which you can use to easily save all the telephone data to your hard drive.

1. Click the 'Backup function' (nr. 12) in the menu on the left.
2. The telephone data will be saved in the installation directory of the SIM card editor. The standard location of this directory is 'C:\Program Files\SIM editor'.

3. You can also choose to export the data of your SIM card manually. In this case you click 'File' and then click 'Export'.
4. Click 'File' and then click 'Import' to replace a currently exported file back to your telephone.

5.0 Frequently Asked Questions

Q: The USB Cardreader is not found automatically.

A 1: Your computer probably has a conflict on the used USB port. Try to use another USB port instead.

A 2: We recommend you to upgrade the drivers of your USB ports when the answer above does not solve the problem. Please contact the manufacturer of your computer for this.

Q: The size of the USB Cardreader is a too large, therefore I can hardly use the other USB ports on my computer. How do I solve this?

A: We recommend you to use the USB extension cable.

Q: The SIM editor asks me to fill in the pin code of my SIM card.

A 1: The SIM card you are using probably needs a pin code. This is the same code you are using when powering on your telephone.

A 2: When you get this message while there is no pin code installed on your SIM card, we recommend you to put the SIM card in the card reader again. The card might have been placed incorrect in the card reader.

6.0 Service and support

This users manual has been carefully written by Eminent's technical experts.

If you have problems installing or using the product, please fill out the support form at the website www.eminent-online.com/support.

Declaration of Conformity

To ensure your safety and compliance of the product with the directives and laws created by the European Commission you can obtain a copy of the Declaration of Conformity concerning your product by sending an e-mail message to: info@eminent-online.com. You can also send a letter to:

Eminent Computer Supplies
P.O. Box 276
6160 AG Geleen
The Netherlands

Clearly state 'Declaration of Conformity' and the article code of the product of which you would like to obtain a copy of the Declaration of Conformity.



Trademarks: all brand names are trademarks and/or registered trademarks of their respective holders.

The information contained in this document has been created with the utmost care. No legal rights can be derived from these contents. Eminent cannot be held responsible, nor liable for the information contained in this document.



Eminent is a member of the Intronic Group