



MANUAL

EM3750 - PCI Soundcard 5.1

WWW.EMINENT-ONLINE.COM

EM3750 - PCI Soundcard 5.1



Warnings and points of attention

Opening a product and/or products may cause serious injuries! Always have products repaired by qualified Eminent personnel!

Table of contents

1.0 Warranty conditions.....	2
2.0 Introduction	2
2.1 Functions and features	3
2.2 Package contents	3
2.3 Soundcard connectors.....	3
3.0 Installation procedure	3
3.1 Installing the Soundcard	3
3.2 Driver installation procedure	4
4.0 Volume and balance	4
5.0 Frequently asked questions.....	5
6.0 Service and Support	5

1.0 Warranty conditions

The five-year Eminent warranty applies for all Eminent products unless mentioned otherwise before or during the moment of purchase. When having bought a second-hand Eminent product the remaining period of warranty is measured from the moment of purchase by the product's first owner. The Eminent warranty applies to all Eminent products and parts inextricably connected to and/or mounted on the main product. Power supply adapters, batteries, antennas and all other products not integrated in or directly connected to the main product and/or products of which, without reasonable doubt, can be assumed that wear and tear show a different pattern than the main product are not covered by the Eminent warranty. Products are not covered by the Eminent warranty when exposed to incorrect/improper use, external influences and/or when opened by parties other than Eminent.

2.0 Introduction

Congratulations with your purchase of this high-quality Eminent product! This product has undergone extensive testing by Eminent's technical experts. Should you experience any problems with this product, you are covered by a five-year Eminent warranty. Please keep this manual and the receipt in a safe place.

Register this product now on www.eminent-online.com and receive product updates!

2.1 Functions and features


The Eminent PCI Soundcard allows you to play and record sound on your computer. Connect up to six speakers for optimal sound. Moreover, the soundcard is fitted with an earphones connection and a game port.

2.2 Package contents

The following parts need to be present in the packing.

- EM3750, PCI Soundcard 5.1.
- Installation CD-rom with drivers and manual.
- Manual.

2.3 Soundcard connectors



- | | |
|-----------------------------|----------------------------------|
| (1) Line-in connector | (5) Center / Subwoofer connector |
| (2) Microphone connector | (6) Game / Midi connector* |
| (3) Front speaker connector | (7) CD-in connector |
| (4) Rear speaker connector | (8) AUX connector |

**You will need a MIDI adapter to be able to connect a MIDI device.*

3.0 Installation procedure

Follow the steps below to install the Soundcard on your PC.

3.1 Installing the Soundcard

1. Remove the PC's main cable from the wall outlet.
2. Remove all cables connected to the PC.
3. Unscrew the cover from the PC case.

4. Insert the Soundcard straight and firmly into an available PCI slot (the short, white connection on the motherboard). The card should preferably not be placed in the first or last PCI slot. Placing the card in the first or last PCI slot can result in hardware conflicts.
5. Attach the card to the chassis of the PC.
6. Close the computer case.
7. Reconnect all cables.
8. Start the PC.

3.2 Driver installation procedure

After Windows has been started the wizard 'New hardware' will appear.

1. Click 'Cancel'.
2. Place the supplied installation CD-rom in the CD-rom or DVD drive of your computer.
3. Check the installation language.
4. Click 'Next'.
5. Select 'Install driver'.
6. Click 'Next'.
7. Follow the instructions on your screen to install the driver.
8. Restart the computer to finish the installation.

You can also start the installation program manually by clicking on 'Start' and then 'Run'. In the text field type 'x:\setup.exe' ('x' is the drive letter of your CD-rom or DVD drive) and click 'OK'.

4.0 Volume and balance

After the computer has been restarted the speaker settings window appears. Here you can select the speaker configuration you wish to use (for instance 2, 4 or 6 speakers).

1. Double click the new icon (the volume controller at the lower-right corner, next to the clock).
2. The volume control window will appear.

In the volume control window you can adjust several sound settings:

- *The balance can be adjusted by dragging the balance bar from left to right.*
- *The volume can be adjusted by dragging the volume bar up or down.*
- *To mute the sound you can check 'Mute'.*
- *By clicking 'Options' and then 'Properties' you can select which devices will be shown in the 'Volume settings' window.*

5.0 Frequently asked questions

Q: Windows does not recognize the Soundcard. How do I solve this?

A: If the Soundcard is not recognized it could indicate a system conflict. Try placing the Soundcard in another PCI slot.

Q: I do not hear any sound after installing the Soundcard.

A: Check if the speakers are powered and connected correctly to the Soundcard. If the speakers are connected correctly and you still do not hear any sound check the volume control window of the Soundcard (see also chapter 4). Maybe the volume control is set to mute or mute all. If this does not solve the problem, the Soundcard may have a conflict.

6.0 Service and Support

This users manual has been carefully written by Eminent's technical experts. If you have problems installing or using the product, please fill out the support form at the website www.eminent-online.com/support.

Declaration of Conformity

To ensure your safety and compliance of the product with the directives and laws created by the European Commission you can obtain a copy of the Declaration of Conformity concerning your product by sending an e-mail message to: info@eminent-online.com. You can also send a letter to:

Eminent Computer Supplies
P.O. Box 276
6160 AG Geleen
The Netherlands

Clearly state 'Declaration of Conformity' and the article code of the product of which you would like to obtain a copy of the Declaration of Conformity.



Trademarks: all brand names are trademarks and/or registered trademarks of their respective holders.

The information contained in this document has been created with the utmost care. No legal rights can be derived from these contents. Eminent cannot be held responsible, nor liable for the information contained in this document.



Eminent is a member of the Intronic Group