


EM6015 Revision 1 Firmware Update Instructions

Nederlandstalige instructies zie pagina 2

English Instructions

Warning ! This firmware is only for EM6015 R1.


Please check the version on the bottom of your EM6015 before proceeding.



This firmware update can only be installed directly on the DVR of the security kit using a USB memory stick. Make sure you have about 20 Mb free space on this USB memory stick.

1.0 On your computer

1. Unzip the files to your desktop. You will see a folder named 'dvrupgrade'.
2. Copy the folder 'dvrupgrade' and its contents to your USB memory stick. It should look like this:



3. Safely remove your USB memory stick from your computer.

2.0 On your DVR


Make sure that your DVR is on and you use the mouse to navigate through the menu.

1. Plug in the USB Memory Stick on the front side of the DVR (upper USB port)
2. Right click on the screen and go to 'Main Menu'.
3. Go to Advanced, go to 'Maintain'.
4. Click on 'Upgrade'.
5. The display will say 'System Update'.
6. The firmware update is finished when the DVR is rebooted.
7. You can now remove the USB memory stick again.

Nederlandstalige Instructies

Let op ! Deze firmware is alleen voor EM6015 R1.

Controleer de versie aan de onderkant van je EM6015 voordat je verder gaat.




Deze firmware update kan alleen direct op de DVR van de security kit uitgevoerd worden d.m.v. een USB geheugen stick.

Zorg ervoor dat je USB geheugen stick minimaal 20 Mb vrije ruimte heeft

1.0 Op je computer

1. Pak het ZIP bestand uit op je bureaublad. Er verschijnt o.a. een map met de naam 'dvrupgrade'.
2. Kopieer de map 'dvrupgrade' met inhoud naar je USB geheugen stick. Dit ziet er daarna als volgt uit:



3. Verwijder de geheugen stick nu van je computer (evt. via Veilig Verwijderen).

2.0 Op je DVR

Zorg ervoor dat je DVR ingeschakeld is en gebruik de muis om door het menu te navigeren.

1. Sluit de USB geheugen stick aan op de USB poort aan de voorzijde van de DVR (bovenste poort)
2. Klik met de rechtermuisknop op het scherm en ga naar 'Main Menu'.
3. Ga naar 'Advanced', ga vervolgens naar 'Maintain'.
4. Klik op 'Upgrade'.
5. Het scherm geeft nu 'System Update' weer.
6. De firmware update is klaar als de DVR opnieuw opgestart is.
7. De USB geheugen stick kan nu weer verwijderd worden.