



EM7180 / EM7080 firmware update

WWW.EMINENT-ONLINE.COM

Firmware Installatie.

Voor Nederlandse gebruikers: Ga naar pagina 3.

Firmware Installation.

For English users: Go to page 5.

EM7280 Firmware update

Inhoudsopgave

1.0 Introductie	3
2.0 Firmware installeren	3
3.0 Opmerking.....	3
4.0 Release notes:	4
5.0 Overige informatie:	4

1.0 Introductie

Deze installatie handleiding zal je helpen de firmware van de EM7280 te installeren. Volg de aangegeven stappen nauwgezet om de firmware correct te installeren.

2.0 Firmware installeren

1. Zet de mediaspeler uit.
2. Download de firmware en sla de firmware op.
3. Pak het gedownloade bestand uit. Het uitgepakte firmware bestand heet 'Install.img'.
4. Plaats het 'Install.img' firmware bestand op een USB stick (In de root). Gebruik bij voorkeur een pas geformatteerde USB stick, er mogen geen andere bestanden op de USB stick aanwezig zijn!
5. Plaats de USB stick in een USB poort van de mediaspeler.
6. Druk de kleine 'restore' knop in, welke je op de onderkant van je mediaspeler kunt vinden.
7. Schakel de mediaspeler in, terwijl je deze knop ingedrukt blijft houden.
8. Na een tijdje (ca. 1 minuut) zal er een upgrade scherm verschijnen.
9. De mediaspeler zal de installatieprocedure zelf doorlopen. Onderbreek deze procedure niet!

3.0 Opmerking

1. Sommige oudere HDMI 1.1/1.2 televisies laten het upgradescherm wellicht niet zien. In dat geval dien je te wachten totdat de mediaspeler zichzelf opnieuw opstart. De installatie van de firmware duurt ongeveer vijf minuten.
2. Het is mogelijk dat oudere en/of kleinere USB geheugensticks niet worden herkend. Wordt je geheugenstick niet herkend, zet dan de mediaspeler uit en probeer de update opnieuw uit te voeren met een andere USB stick.

4.0 Release notes:

Versie 1.0.0.6 'New Gui' (03-05-2012)

- WMA Audio hersteld.
- Probleem met willekeurig herstarten cq. Rebooten van de speler opgelost.
- De snelheid van de gebruikersinterface is verbeterd, en ca 10-25% sneller dan voorgaande versies.
- Third-party apps toegevoegd. Zie bijgevoegd PDF document voor uitgebreide informatie. Een account op <http://thirdparty.eminent-online.com> is vereist voor de correcte werking van het Third-party apps menu.(*)
- Tijdzone gecorrigeerd.
- BTPD en NZBD kunnen via telnet worden uitgeschakeld zodat ze nooit opstarten. Maak hiervoor via telnet de bestanden no_bt看pd of no_nzbd aan in /usr/local/etc. (Bijv. #/touch /usr/local/etc/no_bt看pd.)
- Een aantal overbodige mappen wordt niet meer in de hoofdmap van de harddisk aangemaakt. (Bijv. ThunderDB mappen.)

** Let op: De beschikbaarheid van online services kan variëren en is niet gegarandeerd!*

5.0 Overige informatie:

- Bezoek ook ons Open Source forum om je ervaringen met andere gebruikers te delen. Het Eminent Open Source forum kun je vinden door het volgende in de adresbalk van je browser in te tikken: 'http://opensource.eminent-online.com'
- Bezoek de Eminent website voor de veelgestelde vragen. De veelgestelde vragen kun je vinden door in de adresbalk van je browser in te tikken: 'http://www.eminent-online.com'. Selecteer de EM7280, bij 'Ondersteuning' kun je de 'Veelgestelde vragen' vinden.

EM7280 firmware update

Table of contents

1.0 Introduction	5
2.0 Installing the firmware.....	5
3.0 Remark.....	5
4.0 Release notes:	6
5.0 Other information.....	6

1.0 Introduction

This installation manual guides you to the installation process of the EM7280 firmware. Use the following steps to correctly install the firmware.

2.0 Installing the firmware

1. Turn off your media player.
2. Download the firmware and save the firmware.
3. Unpack the firmware. The unpacked firmware file is named 'install.img'.
4. Copy the 'install.img' file to a USB memory stick. Preferably, make use of a recently formatted USB memory stick. No other files may be present on the memory stick!
5. Place the USB memory stick in a USB port of the media player.
6. Press and hold the small 'Restore' button that you can find on the bottom of your mediaplayer.
7. Turn on the media player and keep holding the 'Restore' button.
8. After a short while (around 1 minute) an upgrade screen will appear.
9. The media player will install the new firmware automatically. Do not interrupt this procedure!

3.0 Remarks

1. Some older HDMI 1.1/1.2 televisions may not show the progress bar. In that case, you just need to wait until the media player restarts. The firmware installation process will take about 5 minutes to complete.
2. It is possible some older/smaller USB memory sticks will not be recognized. If so, turn off the media player en retry the update using another USB memory stick.

4.0 Release notes:

Version 1.0.0.6 'New Gui' (03-05-2012)

- WMA Audio restored.
- A problem with random reboots/restarts has been solved.
- User interface speed has been improved by around 10-25% compared to previous versions.
- Enabled third-party apps icon & functions. Please see the additional PDF document for more information. An account on <http://thirdparty.eminent-online.com> is required for this functionality to work.(*)
- Time Zone has been corrected.
- BTPD and NZBD startup can be disabled completely. Create files named 'no_bt看pd' or 'no_nzbd' in /usr/local/etc using telnet.
(For example by doing a #/touch /usr/local/etc/no_bt看pd.)
- A number of non-needed folders will no longer be created in the root folder of your media player. (For example, the 'ThunderDB' folder.)

Note: The availability of online services can vary and therefore can not be guaranteed!

5.0 Other information

- Visit our Open Source forum to exchange your experiences with other Eminent users. The Eminent Open Source forum can be typing the following in the address bar of your browser: 'http://opensource.eminent-online.com'
- Also visit our website for Frequently Asked Questions. Go to 'www.eminent-online.com' en search for your product. At 'Support', you will find the Frequently asked questions



WWW.EMINENT-ONLINE.COM

Trademarks: all brand names are trademarks and/or registered trademarks of their respective holders.

The information contained in this document has been created with the utmost care. No legal rights can be derived from these contents. Eminent cannot be held responsible, nor liable for the information contained in this document.



Eminent is a member of the Intronics Group